


TOP AND CABINET PARTS

**For Model: WTW5300VW1
(White)**

AUTOMATIC
WASHER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CABINET PARTS

For Model: WTW5300VW1
(White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts Installation Instructions
	W10200331	English/French
	W10200662	Spanish
		Feature Sheet
	W10200856	English/French
	W10200857	Spanish
		Use & Care Guide
	W10200828	English/French
	W10200829	Spanish
	W10062889	Energy Guide
	8577358	Wiring Diagram

Following May Be Purchased


DO-IT-YOURSELF REPAIR MANUALS

	4313896	Manual, Washer
2	W10194572	Top
3	62750	Spacer, Cabinet To Top (4)
4	W10171313	Lid
5	63424	Cabinet
6	62780	Clip, Top & Cabinet & Rear Panel (2)
7	W10192089	Dispenser, Bleach
8	3351614	Screw, Ground
9	8318084	Switch, Lid
10	W10119828	Screw, Lid Hinge Mounting (4)
11	8559336	Hinge, Lid (L.H.)
12	91770	Hinge, Lid (R.H.)
13	9724509	Bumper, Lid (2)
14	8319539	Bearing, Lid Hinge (2)
15	3390631	Screw 10-16 X 3/8 (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROLS AND REAR PANEL PARTS

For Model: WTW5300VW1
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROLS AND REAR PANEL PARTS


For Model: WTW5300VW1
(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10044160	Harness, Wiring (For Detail See Pages 9 & 10)	14	8578842	Cord, Power (Includes Item 15)	27	W10184148	Switch, Water Temperature (ATC)
2	9740848	Screw, 8/18 x 1/2	15	3952821	Strain Relief, Power Cord	28	3949187	Switch, Rotary
3	3347868	Cable Tie	16	8566035	Cap, End (L.H.) (Includes Item 40)	29	8572717	Capacitor, Motor Start
4	8577378	U-Bend, Drain Hose	17	8566032	Cap, End (R.H.) (Includes Item 40)	30	3363366	Clamp, Hose
5	8568314	Strap, Console (2)	18	3979347	Valve, Water Inlet W/Thermistor	31	8317496	Clamp, Hose
6	W10194449	Panel, Rear	19	8541668	Clamp, Hose	32	3951449	Hose, Pump To Tub (Includes Item 30)
7	62747	Pad, Rear Panel	20	62863	Screw, 10-16 x 3/8	33	3400073	Screw, Ground
8	W10189267	Drain Hose Assembly (Includes Item 19)	21	301958	Clamp, Hose	34	3400818	Screw, Timer Mounting
9	8577356	Timer, Control (60 Hz.) (Motor Not A Service Part)	22	W10190501	Hose, Vacuum Break	35	W10196930	Panel, Console
10	3351614	Screw, Ground	23	370450	Clamp, Hose	36	W10034730	Knob, Timer
11	90767	Screw, 8/18 x 3/8	24	W10190514	Break, Vacuum	37	8566018	Dial, Timer
12	8577843	Switch, Water Level	25	8318046	Clip, Capacitor	38	W10034380	Knob, Control
13	8566003	Bracket, Control	26	8519200	Support, Rear Panel	39	8536939	Clip, Knob
						40	8312709	Clip, Console
						41	8314879	Shield, Suds
						42	8055003	Clip, Harness & Pressure Hose

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS

For Model: WTW5300VW1
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS


For Model: WTW5300VW1
(White)

Illus. No.	Part No.	DESCRIPTION
1	8575076	Dispenser, Fabric Softener
2	358237	Screw & Washer
3	3949550	Washer
4	3951608	Spacer, Thrust
5	3951632	Agitator
6	W10168523	Tub Ring
7	3359585	Gasket, Tub Ring
8	21366	Nut, Spanner
9	8526016	Basket & Balance Ring
10	387240	Balance Ring
11	63849	Tub
12	389140	Block, Drive
13	383727	Gasket, Centerpost
14	3347780	Hose, Pressure Switch
15	2219077	Clip, Pressure Switch Hose
16	3354733	Cap, Barrier
17	W10072840	Seal, Inner Cap
18	3366877	Dog, Agitator (4)
19	3952374	Bearing, Driven Cam
20	3951682	Cam, Driven
21	3363003	Clothes Mover
22	3951744	Agitator (Complete)
23	3354845	Clip, Agitator
24	8543666	Washer, Agitator

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Model: WTW5300VW1
(White)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake & Drive Tube (Complete) (Refer to Page 11 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3951311	Clutch (Complete)
6	3951308	Band & Lining, Clutch (Includes Items 7 & 8)
7	62646	Cap, Clutch Spring (2)
8	3946792	Spring, Clutch
9	3360630	Gearcase (Complete) (Refer To Page 12 For Further Breakdown)
10	3357334	Screw, Gearcase To Base (3)


Illus. No.	Part No.	DESCRIPTION
11	62611	Plate, Motor Mount To Gearcase
12	62691	Grommet, Motor (4)
13	3364003	Coupling, Motor And Isolation
14	8577374	Seal
15	3355454	Clip, Anti-Rattle
16	3400516	Screw
17	W10086010	Retainer, Motor (2)
18	3362089	Shield, Tub To Motor
19	8528157	Motor, Main Drive
20	3952056	Switch, Main Drive Motor
21	8546127	Retainer, Pump (2)
22	3363394	Pump (Complete)
23	3387485	Screw, 10-16 x 5/8
24	3946532	Shield, Motor



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MACHINE BASE PARTS

For Model: WTW5300VW1
(White)




Illus. No.	Part No.	DESCRIPTION
1	3400076	Screw, Bracket Mounting (10-32 x 5/8)
2	64067	Bracket, Spring Outer (2)
3	63907	Spring, Suspension (3)
4	8575214	Support & Brake, Tub
5	64065	Bracket, Spring Outer (L.F.)
6	63466	Link, Leveling Mechanism (2)
7	62597	Spring, Leveling Mechanism
8	62837	Pin, Knurled
9	62596	Foot, Rear (2)
10	8546455	Bearing, Centerpost (2)
11	357409	Seal, Centerpost (3)
12	388492	Spring, Counterweight
13	62568	Pad, Plate
14	3946509	Plate, Suspension (Includes Item 13)
15	3363660	Pad, Base
16	3946512	Base Assembly (Includes Items 6, 7, 8, 9, 13, 14, 15 & 22)
17	3359452	Nut, Lock (2) (3/8-16)
18	W10001130	Foot, Front (2)
19	8577376	Seal, Centerpost
20	285203	Centerpost Bearing Kit (Includes Items 10, 11 & 19)
21	63134	Ring, Sound Deadening
22	W10145155	Retainer, Suspension Spring

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Model: WTW5300VW1
(White)



WH2J

WIRING HARNESS PARTS

For Model: WTW5300VW1
(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3349557	Retainer, Harness	9	62889	Receptacle, Terminal	16	3390423	Block, Disconnect (12-Way)
2	388498	Clip, Harness			(3-Way)	17	3347730	Receptacle (6-Way)
3	3347812	Clip, Harness	10	353424	Plug, Terminal (3-Way)	18	3948617	Connector (T.P.A.) (3-Circuit)
4	3352501	Clip, Harness (Push-In)	11	62505	Block, Disconnect (Motor 2 Speed)	19	3360056	Plug (T.P.A.) (3-Circuit)
5	90016	Clip, Harness (Half-Harness)	12	3347243	Block, Disconnect			(Pressure Switch)
6	3390496	Clip, Harness	13	63523	Protector	20		Block, Connector
7	389379	Retainer, Harness	14	717252	Connector (2-Way)		3354925	Natural
8		Timer, Block Disconnect	15	3352944	Clip, Harness		3354926	Red
	3948614	Natural						
	352089	Black						


**FOR COMPLETE WIRING HARNESS REFER TO
CONTROL AND REAR PANEL PARTS PAGE**

WH2J

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BRAKE AND DRIVE TUBE PARTS

For Model: WTW5300VW1
(White)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	356427	Seal, Drive Tube
4	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
5	64035	Ring, Retaining
6	64232	Shoe, Brake (2)
7	62703	"T" Bearing, Spin Tube
8	3353956	Cap, Brake Spring (2)
9	387806	Spring, Brake
10	3355360	Sleeve, Brake Spring
11	661516	Cam, Brake Release
12	63022	Sleeve, Cam
13	64194	Driver, Brake Cam
14	90368	Ring, Retaining

FOLLOWING PARTS NOT ILLUSTRATED


285208 Lubricant
(Use Only In Brake Shoe Assembly On Roller & Pin)

BD-315-B

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GEARCASE PARTS

For Model: WTW5300VW1
(White)



Illus. No.	Part No.	DESCRIPTION
1	3360630	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 and 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 and 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389230	Bottom and Pinion, Gearcase
21	285352	Seal, Thrust Plug
22	3351614	Screw, Gearcase Cover, Mounting (8) (10-24 x 3/8)
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	3349296	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: WTW5300VW1
(White)

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>		
	350938	Primer, Gray
	350930	White
<u>PAINT, BULK (1 qt.)</u>		
	799344	White (Uncut)

Illus. No.	Part No.	DESCRIPTION
<u>OIL</u>		
	350572	Oil, Gearcase (16 Oz.)
<u>LUBRICANT</u>		
	285208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)
<u>SEALER</u>		
	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)

Illus. No.	Part No.	DESCRIPTION
<u>ACCESSORY PARTS</u>		
	367031	Drain Protector
	280129	Siphon Break Kit
	280130	Drain Hose Adapter Kit
	280131	Drain Hose Extension Kit
	8212546RP	Inlet Hoses, 4 Ft. (Two Black Hoses W/Straight Ends & 4 Rubber Washers)
	8212641RP	Inlet Hoses, 5 Ft. (Two Black Hoses W/Straight Ends & 4 Rubber Washers)
	8212656RP	Inlet Hoses, 10 Ft. (Two Black Hoses W/Straight Ends & 4 Rubber Washers)
	8212545RP	Inlet Hoses, 5 Ft. (One Red Hose & One Blue Hose W/Straight Ends & 4 Rubber Washers)
	8212487RP	Inlet Hoses, 5 Ft. (Two Braided Hoses W/Straight Ends & 4 Rubber Washers)
	8212637RP	Inlet Hoses, 6 Ft. (Two Black Hoses W/One Straight End & One 90 Degree End & 4 Rubber Washers)
	8212638RP	Inlet Hoses, 6 Ft. (Two Braided Hoses W/One Straight End & One 90 Degree End & 4 Rubber Washers)
	285448A	Hose Washers (Package of 4)
	285452A	Hose Screen (Package of 2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST